










US MODEL NUMBER	Description	Picture
USFS-4-6	Splash-mounted faucet 4" centers, swing nozzle, 6" long spout Carton box packing	
USFS-4-8	Splash-mounted faucet 4" centers, swing nozzle, 8" long spout Carton box packing	
USFS-4-10	Splash-mounted faucet 4" centers, swing nozzle, 10" long spout Carton box packing	
USFS-4-12	Splash-mounted faucet 4" centers, swing nozzle, 12" long spout Carton box packing	
USFS-4-14	Splash-mounted faucet 4" centers, swing nozzle, 14" long spout Carton box packing	
USFS-4-16	Splash-mounted faucet 4" centers, swing nozzle, 16" long spout Carton box packing	
USFS-4-18DJ	Splash-mounted faucet 4" centers, swing nozzle, 18" long double-jointed spout Carton box packing	
USFS-4-6B	Splash-mounted faucet 4" centers, swing nozzle, 6" long spout Carton box packing	
USFS-4-8B	Splash-mounted faucet 4" centers, swing nozzle, 8" long spout Carton box packing	
USFS-4-10B	Splash-mounted faucet 4" centers, swing nozzle, 10" long spout Carton box packing	
USFS-4-12B	Splash-mounted faucet 4" centers, swing nozzle, 12" long spout Carton box packing	
USFS-4-4G	Splash-mounted faucet 4" centers, 3 1/2" gooseneck spout Carton box packing	
USFS-4-6G	Splash-mounted faucet 4" centers, 6" gooseneck spout Carton box packing	
USFS-4-8G	Splash-mounted faucet 4" centers, 8 1/2" gooseneck spout Carton box packing	
USFS-4-4GB	Splash-mounted faucet 4" centers, 3 1/2" gooseneck spout Carton box packing	
USFS-4-6GB	Splash-mounted faucet 4" centers, 6" gooseneck spout Carton box packing	
USFS-4-9GB	Splash-mounted faucet 4" centers, 8 1/2" gooseneck spout Carton box packing	

<b>USFD-4-4G</b>	Deck-mounted faucet 4" centers, 3 1/2" gooseneck spout Carton box packing	
<b>USFD-4-6G</b>	Deck-mounted faucet 4" centers, 6" gooseneck spout Carton box packing	
<b>USFD-4-9G</b>	Deck-mounted faucet 4" centers, " gooseneck spout Carton box packing	
<b>USFD-4-6</b>	Deck-mounted faucet 4" centers, swing nozzle, 6" long spout Carton box packing	
<b>USFD-4-8</b>	Deck-mounted faucet 4" centers, swing nozzle, 8" long spout Carton box packing	
<b>USFD-4-10</b>	Deck-mounted faucet 4" centers, swing nozzle, 10" long spout Carton box packing	
<b>USFD-4-12</b>	Deck-mounted faucet 4" centers, swing nozzle, 12" long spout Carton box packing	
<b>USFD-4-14</b>	Deck-mounted faucet 4" centers, swing nozzle, 14" long spout Carton box packing	
<b>USFD-4-16</b>	Deck-mounted faucet 4" centers, swing nozzle, 16" long spout Carton box packing	
<b>USFD-4-16</b>	Deck-mounted faucet 4" centers, swing nozzle, 18" long double-jointed spout Carton box packing	
<b>USFD-4-6B</b>	Deck-mounted faucet 4" centers, swing nozzle, 6" long spout Carton box packing	
<b>USFD-4-8B</b>	Deck-mounted faucet 4" centers, swing nozzle, 8" long spout Carton box packing	
<b>USFD-4-10B</b>	Deck-mounted faucet 4" centers, swing nozzle, 10" long spout Carton box packing	
<b>USFD-4-12B</b>	Deck-mounted faucet 4" centers, swing nozzle, 12" long spout Carton box packing	
<b>USFD-4-14B</b>	Deck-mounted faucet 4" centers, swing nozzle, 14" long spout Carton box packing	
<b>USFD-4-16B</b>	Deck-mounted faucet 4" centers, swing nozzle, 16" long spout Carton box packing	