



## US NSF EQUIPMENT STANDS

| MODEL NUMBER  | DESCRIPTION  | Photo   |
|---------------|--|---|
| USES-2412-418 | Equipment stand 24"X12"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing            |  |
| USES-2415-418 | Equipment stand 24"X15"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing            |   |
| USES-2418-418 | Equipment stand 24"X18"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing            |   |
| USES-2424-418 | Equipment stand 24"X24"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing            |   |
| USES-2430-418 | Equipment stand 24"X30"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing            |   |
| USES-2436-418 | Equipment stand 24"X36"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing            |   |
| USES-2448-418 | Equipment stand 24"X48"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing            |   |
| USES-2460-418 | Equipment stand 24"X60"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel, <b>6 Galvanized legs and socket, plastic bullet foot, carton box packing</b> |   |
| USES-2472-418 | Equipment stand 24"X72"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel, <b>6 Galvanized legs and socket, plastic bullet foot, carton box packing</b> |   |

## US NSF EQUIPMENT STANDS

| MODEL NUMBER  | DESCRIPTION  | Photo   |
|---------------|--|---|
| USES-2484-418 | Equipment stand 24"X84"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |  |
| USES-2496-418 | Equipment stand 24"X96"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |   |
| USES-3012-418 | Equipment stand 30"X12"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |   |
| USES-3015-418 | Equipment stand 30"X15"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |   |
| USES-3018-418 | Equipment stand 30"X18"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |   |
| USES-3024-418 | Equipment stand 30"X24"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |   |
| USES-3030-418 | Equipment stand 30"X30"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |   |
| USES-3036-418 | Equipment stand 30"X36"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |   |
| USES-3048-418 | Equipment stand 30"X48"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |   |

## US NSF EQUIPMENT STANDS

| MODEL NUMBER  | DESCRIPTION  | Photo |
|---------------|--|-------|
| USES-3060-418 | Equipment stand 30"X60"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |       |
| USES-3072-418 | Equipment stand 30"X72"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |       |
| USES-3084-418 | Equipment stand 30"X84"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |       |
| USES-3096-418 | Equipment stand 30"X96"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |       |
| USES-2412-416 | Equipment stand 24"X12"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |
| USES-2415-416 | Equipment stand 24"X15"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |
| USES-2418-416 | Equipment stand 24"X18"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |
| USES-2424-416 | Equipment stand 24"X24"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |
| USES-2430-416 | Equipment stand 24"X30"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |

## US NSF EQUIPMENT STANDS

| MODEL NUMBER  | DESCRIPTION  | Photo |
|---------------|--|-------|
| USES-2436-416 | Equipment stand 24"X36"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |
| USES-2448-416 | Equipment stand 24"X48"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |
| USES-2460-416 | Equipment stand 24"X60"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |       |
| USES-2472-416 | Equipment stand 24"X72"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |       |
| USES-2484-416 | Equipment stand 24"X84"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |       |
| USES-2496-416 | Equipment stand 24"X96"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |       |
| USES-3012-416 | Equipment stand 30"X12"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |
| USES-3015-416 | Equipment stand 30"X15"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |
| USES-3018-416 | Equipment stand 30"X18"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |

## US NSF EQUIPMENT STANDS

| MODEL NUMBER   | DESCRIPTION   | Photo |
|----------------|---|-------|
| USES-3024-416  | Equipment stand 30"X24"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides 18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |
| USES-3030-416  | Equipment stand 30"X30"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides 18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |
| USES-3036-416  | Equipment stand 30"X36"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides 18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |
| USES-3048-416  | Equipment stand 30"X48"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides 18GA.galvanized undershelf and hat channel Galvanized leg and socket, plastic bullet foot, carton box packing          |       |
| USES-3060-416  | Equipment stand 30"X60"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides 18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |       |
| USES-3072-416  | Equipment stand 30"X72"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides 18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |       |
| USES-3084-416  | Equipment stand 30"X84"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides 18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |       |
| USES-3096-416  | Equipment stand 30"X96"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides 18GA.galvanized undershelf and hat channel <b>6 Galvanized leg and socket, plastic bullet foot, carton box packing</b> |       |
| USESS-2412-418 | Equipment stand 24"X12"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides 18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing                         |       |

## US NSF EQUIPMENT STANDS

| MODEL NUMBER   | DESCRIPTION   | Photo |
|----------------|---|-------|
| USESS-2415-418 | Equipment stand 24"X15"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2418-418 | Equipment stand 24"X18"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2424-418 | Equipment stand 24"X24"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2430-418 | Equipment stand 24"X30"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2436-418 | Equipment stand 24"X36"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2448-418 | Equipment stand 24"X48"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2460-418 | Equipment stand 24"X60"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |
| USESS-2472-418 | Equipment stand 24"X72"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |
| USESS-2484-418 | Equipment stand 24"X84"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |
| USESS-2496-418 | Equipment stand 24"X96"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |

## US NSF EQUIPMENT STANDS

| MODEL NUMBER   | DESCRIPTION   | Photo |
|----------------|---|-------|
| USESS-3012-418 | Equipment stand 30"X12"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3015-418 | Equipment stand 30"X15"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3018-418 | Equipment stand 30"X18"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3024-418 | Equipment stand 30"X24"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3030-418 | Equipment stand 30"X30"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3036-418 | Equipment stand 30"X36"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3048-418 | Equipment stand 30"X48"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3060-418 | Equipment stand 30"X60"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |
| USESS-3072-418 | Equipment stand 30"X72"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |
| USESS-3084-418 | Equipment stand 30"X84"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |

## US NSF EQUIPMENT STANDS

| MODEL NUMBER   | DESCRIPTION   | Photo |
|----------------|---|-------|
| USESS-3096-418 | Equipment stand 30"X96"X24"H, 18GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |
| USESS-2412-416 | Equipment stand 24"X12"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2415-416 | Equipment stand 24"X15"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2418-416 | Equipment stand 24"X18"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2424-416 | Equipment stand 24"X24"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2430-416 | Equipment stand 24"X30"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2436-416 | Equipment stand 24"X36"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2448-416 | Equipment stand 24"X48"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-2460-416 | Equipment stand 24"X60"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |
| USESS-2472-416 | Equipment stand 24"X72"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |



## US NSF EQUIPMENT STANDS

| MODEL NUMBER   | DESCRIPTION   | Photo |
|----------------|---|-------|
| USESS-2484-416 | Equipment stand 24"X84"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |
| USESS-2496-416 | Equipment stand 24"X96"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |
| USESS-3012-416 | Equipment stand 30"X12"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3015-416 | Equipment stand 30"X15"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3018-416 | Equipment stand 30"X18"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3024-416 | Equipment stand 30"X24"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3030-416 | Equipment stand 30"X30"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3036-416 | Equipment stand 30"X36"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3048-416 | Equipment stand 30"X48"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel S/S leg and socket, S/S bullet foot, carton box packing          |       |
| USESS-3060-416 | Equipment stand 30"X60"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |

## US NSF EQUIPMENT STANDS

| MODEL NUMBER   | DESCRIPTION   | Photo |
|----------------|---|-------|
| USESS-3072-416 | Equipment stand 30"X72"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |
| USESS-3084-416 | Equipment stand 30"X84"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |
| USESS-3096-416 | Equipment stand 30"X96"X24"H, 16GA.430S/S top shelf with 2" turn up on left-rear-right sides<br>18GA.430S/S undershelf and hat channel <b>6 S/S leg and socket, S/S bullet foot, carton box packing</b> |       |